



**NOTES:**

1. METER BOX BLOCK OUT IS ONLY TO BE USED IN CONCRETE DRIVEWAYS OR SIDEWALKS.
2. DISTRICT APPROVAL IS REQUIRED PRIOR TO INSTALLING METER BOX IN DRIVEWAYS.
3. BACKFILL FOR METER BOX BASE IS TO BE COMPACTED 1 1/4" BASE COURSE OR 3/4" TOP COURSE CRUSHED ROCK.
4. CONCRETE FINISH SHALL MATCH ADJACENT CONCRETE DRIVEWAY OR SIDEWALK FINISH.

## METER BOX BLOCK OUT FOR DRIVEWAYS AND SIDEWALKS

NOT TO SCALE

**DETAIL APPROVALS**  
**EDITOR** TMC  
**MANAGER** SJD

**NORTHSHORE UTILITY DISTRICT**  
 2024 STANDARD WATER DETAILS